




LINE

LINE: 2 Points


- click the  icon
- specify **first point** (left-click)
- specify **second point**
- **Right-click** to 'back' or press 'Esc' to exit.




2 points with more detail (tips for drawing a specific length of a line; type the BOLD one into command-line).


- specify the First point (left-click).
- **@50<0** for straight line.
- **@50,50** for Square or **@50,30** for Rectangle.
- **@60<120** for 60mm line at 120 degrees. (try {-} (minus) symbol before 'degree' and see what happen!!)


LINE: Angle

- click the  icon
- enter **angle** (see 'tool option')
- enter **length**
- specify **start, middle, or end snap point**
 - specify **position**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Horizontal

- click the  icon
- enter **length**
- specify **start, middle, or end snap point**
 - specify **position**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Vertical

- click the  icon
- enter **length**
- specify **start, middle, or end snap point**
 - specify **position**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Rectangle

- click the  icon
- specify **first corner**
- specify **second corner**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Parallel through point

- click the  icon
- select **entity**
- specify through **point** (click at specific point or anywhere to repeat the process)
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Parallel

- click the  icon
- enter the **distance** and **number** of copies required OR
 - select **entities** and repeat it as required
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Bisector

- click the  icon
- enter **length** and **number** (from tool option)
 - select **first line**
 - select **second line**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Tangent (P,C)

- click the  icon
- specify **point**
- select **circle, arc or ellipse**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Tangent (C,C)

- click the 
- select **first circle or ellipse**
- select **second circle or ellipse**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Tangent Orthogonal

- click the  icon
- select a **line**
- select **circle, arc or ellipse**
- **Right-click** to 'back' or press 'Esc' to exit





LINE: Orthogonal

- click the  icon
- select **line**
- select **circle, arc or ellipse**
- **Right-click** to 'back' or press 'Esc' to exit







LINE: Relative Angle

- click the  icon
- enter **angle** and **length**
 - select **base entity**
 - select **position**
- **Right-click** to 'back' or press 'Esc' to exit



LINE: Polygon [(Cen,Cor), (Cen,Tan), (Cor,Cor)]

- click the  icon
 - enter **number** of sides as required
 - specify **center**
 - specify **corner**
- click the  icon
 - enter **number** of sides as required
 - specify **center**
 - specify **tangent**
- click the  icon
 - enter **number** of sides as required
 - specify **first corner**
 - specify **second corner**
- **Right-click** to 'back' or press 'Esc' to exit



From:

<https://dokuwiki.librecad.org/> - **Wiki**

Permanent link:

<https://dokuwiki.librecad.org/doku.php/usage:line>



Last update: **2020/06/18 07:31**